BEST LEARNING
Enriching education since 1984

Twirlzzle

Alphabet Fun



INTRODUCTION

Soar into a world of fun and learning with **Twirlzzle**! Twirl the wheels to find knowledge and enjoy hours of entertainment.

In this set, children will embark on an alphabet adventure, exploring letters from A to Z with pronunciations, spelling, and vocabulary. Unleash creativity and imagination by combining different content of wheels to form amusing sentences. Interactive quiz games offer engaging ways to test understanding. Delightful children's songs add a touch of whimsy to learning. This adorable tutor also transforms into a functional musical nightlight with a built-in timer.

Every twirl comes surprise. Make learning fun. That's **Twirlzzle**! (2+ years)

INCLUDED IN THIS PACKAGE

- **Twirlzzle**

ADVICE


- For best performance, please make sure to turn the unit OFF before inserting or removing batteries. Otherwise, the unit may malfunction.
- All packing materials, such as tape, plastic, sheets, packaging locks, wire ties and tags are not part of this toy, and should be discarded for your child's safety.
- Please keep this user's manual as it contains important information.
- Please protect the environment by not disposing of this product with household waste.

⚠ WARNING!

- This toy produces flashes that may trigger epilepsy in sensitized individuals.

GETTING STARTED


Take the product out of the storage slot.



Battery Installation

The product operates on 3 AAA (LR03) batteries.

1. Locate the battery cover on the bottom of the unit and open it with a screwdriver.
2. Insert 3 AAA (LR03) batteries as illustrated.
3. Close the battery cover and screw it back.



Start Playing


1. Once batteries are installed, twirl the **Modes wheel** from **Off** to the other modes, then **Twirlzzle** is live.
2. For shutdown, twirl the **Modes wheel** back to **Off.**



SLEEP MODE

1. If the product is not active for more than 2 minutes, it will automatically go into sleep mode to save power.
2. To wake up, press **Enter button** again to restart the game.

FUNCTIONS



High-quality speaker
Provides users with an excellent audio experience while playing and learning.

Alphabet fun!

Enter button
Press this nose-shaped button to learn more, or enter your answers to questions, or confirm the customized user setting.

Modes wheel (10 modes including **Off**)
Choose any of the modes you want.



Functional wheels
Once enter a mode, follow the instruction to operate functional wheels: **A**, **B**, and **C**.

Wheel A (10 squares)
Includes 9 animals
and 1 treasure box.

Wheel B (10 squares)
Includes 9 musical instruments
and 1 treasure box.

Wheel C (10 squares)
Includes 9 vehicles
and 1 treasure box.

LED lights
The central lights indicate the user's actions and progress while playing or as a nightlight.

Requires 3 AAA batteries
For protecting the environment, we recommend using safe and qualified rechargeable batteries as the product may consume electricity fast since it can use as a musical nightlight. For battery safety, please see page 6.

MODES WHEEL

The modes wheel has a total of 10 modes include **Off**. Once twirl the mode from **Off** to the others, the fun begins. Let's start the adventure of the alphabet.

Learning modes

Alphabet Fun
Learn the letters A to Z with pronunciations and words. Includes an ABCs song.

Word Fun
Discover new vocabulary and their introductions. Includes a Vocabulary song.

Sentence Fun
Form amusing sentences by connecting different content from functional wheels. Includes a Sentence song.

Quiz modes

Alphabet Game
Challenge quizzes based on the learned from the mode **Alphabet Fun**.

Word Game
Challenge quizzes based on the learned from the mode **Word Fun**.

Sentence Game
Challenge quizzes based on the learned from the mode **Sentence Fun**.

1. Choose a learnig mode, and twirl **Functional wheels** to learn and play.
2. Press **Enter button** to learn more.

Tip: The **treasure box** of each wheel can act as a **mute** or **blank** function.

3. Connect **3 treasure boxes** to play thematic songs.

Tip: Add more sounds by twirling **Functional wheels** while the song is playing.



Tip: Under the condition that all **3 treasure boxes** are connected, press **Enter button** can swap the song for **vocal** or **off-vocal** or **cancel**.

1. Choose a quiz mode, listen to the question, and locate your answer by **Functional wheels**.
2. Press **Enter button** to see if your answer is correct.
3. It will release a new question after getting correct or 3 wrong tries of a question.
4. To repeat the question, idle for 30 seconds or after a wrong answer.

Tip: Make good use of the **treasure box(es)** then press **Enter button** to repeat the question without using answering chances.

Auditory fun

Music Party

With no interference from voice, only to enjoy the delightful music and the amusing sounds of animals, musical instruments, and vehicles.

1. Twirl **Functional wheels** to play the sounds and music.
2. Press **Enter button** to swap sounds between layers **A** and **C** as **B** keeps background music.

Tip: Find more sounds in **treasure boxes**.

- **A:** 3 types of drum sounds and **mute**
- **B:** 4 pieces of music and **mute**
- **C:** 3 types of cymbal sounds and **mute**


Bedtime

Musical Nightlight

Use as a musical nightlight with various lighting options, sounds of nature and environment, and loop melodies. Includes a timer for **15 minutes** and **30 minutes**.

1. **Press and hold Enter button** for 2 seconds to interchange the timer.
   - **15 minutes** (will hear **one beep**)
   - **30 minutes** (will hear **two beeps**)

   Once the timer has been changed, it restarts the timer right away.
2. Press **Enter button** to swap 24 lighting options, including light off.
3. Twirl **Functional wheels** to play the sounds or loop melodies.



General setting

User Setting

Customize the general setting for colors of lights and levels of volume.

1. Twirl **Functional wheels** to locate your setting.
2. Press **Enter button** to confirm your setting.

FUNCTIONAL WHEELS

There are three functional wheels: **A**, **B**, and **C**, for learning animals, musical instruments, and vehicles. Each wheel has 9 squares for letters and words with images, and 1 square with a treasure box image acts as mute or blank or the collection of sounds, songs, and music.



CARE AND MAINTENANCE

- Keep product away from foods and beverages.
- Clean with a slightly damp cloth (cold water) and mild soap.
- Never submerge the product in water.
- Remove batteries during prolonged storage.
- Avoid exposing product to extreme temperatures.

BATTERY SAFETY

- Batteries are small parts and choking hazards to children, must be replaced by an adult.
- Follow the polarity (+/-) diagram in the battery compartment.
- Promptly remove dead batteries from the toy.
- Dispose of used batteries properly.
- Remove batteries from prolonged storage.
- Only batteries of the same type as recommended are to be used.
- **DO NOT** incinerate used batteries.
- **DO NOT** dispose of batteries in fire, as batteries may explode or leak.
- **DO NOT** mix old and new batteries.
- **DO NOT** mix alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH) batteries.
- **DO NOT** recharge non-rechargeable batteries.
- **DO NOT** short-circuit the supply terminals.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.

CONFORMS TO
CE EN71
UKCA
ASTM F963